



- Expand the reach of your Ring Alarm Base Station to your Ring Alarm components
- Easy installation with no tools required
- Plugs into standard wall outlets
- Requires the Ring Alarm Base Station and only boosts the Ring Alarm system network